



BENELLI TNT 899S my 08/11

product	code	description
Monoshock (R-L-P)	MB101.1KD	M46KD std
Monoshock (C-R-L-P)	MB101.09K	M46K std
Monoshock (CH-CL-R-L-P)	MB101.09R	M46R Racing (no hydraulic preload unit)

Note: the M46R is supplied without the hydraulic spring preload



M46R



M46K

on demand **Dark Series**



M46KD



High speed
Low speed
Compression
adjustment



Compression
adjustment



Standard
Preload
adjustment



Rebound
adjustment



Length
adjustment

CH = HighSpeed Comp. adj. / regolazione Compressione AV
CL = LowSpeed Comp. adj. / regolazione Compressione BV
C = Compression adj. / regolazione Compressione
R = Rebound adj. / regolazione Estensione
L = Length adjustment / regolazione Interasse
P = spring Preload by ring / precarico molla standard
HP = hydraulic spring preload adj. / precarico molla idraulico